

Amount of remaining fuel [REMAIN] (Only reserve fuel mode)

When the low fuel indicator lights and the low fuel pop-up information appears, the estimated amount of remaining fuel can be selected.

Display range: 0.9 to 0.2 GAL (gallon) or 4.0 to 1.0 L (liters)

- Below 0.2 GAL (1.0 L): "-.-" is displayed.

The amount of remaining fuel is calculated based on the driving states.

The indicated amount of remaining fuel may be different from the actual amount.



REMAIN
0.6 GAL

When "-.-" is displayed except for the above-mentioned cases, go to your dealer for service.