


To switch the multi-information display

To select the display area, repeatedly press the **MODE** button.

- ▶ Can not select the INFO 3 display while pop-up information displayed. ➡ **P.90**

If the **MODE** button is not pressed within 10 seconds, the display returns to the riding mode display.





Riding mode ➡ **P.101**



INFO 3 display ➡ **P.39**

➡ Press the **MODE** button

INFO 1 display ➡ **P.28**



INFO 2 display ➡ **P.31**