


# Parts Location



Rear brake fluid reservoir  
▶ P.72

Battery ▶ P.65

Main fuse ▶ P.92

Fuse box ▶ P.91

Front brake fluid reservoir  
▶ P.72

Throttle grip ▶ P.80

Coolant reserve tank ▶ P.70

Engine oil fill cap ▶ P.68

Engine oil dipstick ▶ P.68