

Instruments (Continued)

- Setting of blinking RPM (**Sport+** mode)
Each time **SEL** button is pressed, the blinking RPM set value increase by 250 r/min (rpm) (one segment). When the set value exceeds the allowable range, the RPM set value automatically returns to 4,000 r/min (rpm).

▶ Press and hold to advance the blinking RPM setting value fast.

Available Setting Range
4,000 -to- 14,000 r/min (rpm)

- Press **SET** button. The blinking RPM (**Sport+** mode) is set, and then the display moves to the setting of blinking RPM (**Sport** mode).

- Setting of blinking RPM (**Sport** mode)
Follow steps **2** under "Setting of blinking RPM (**Sport+** mode)".

Available Setting Range
4,000 -to- 14,000 r/min (rpm)

- Press **SET** button. The blinking RPM (**Sport** mode) is set, and then the display moves to the setting of blinking RPM (**Comfort** mode).

- Setting of blinking RPM (**Comfort** mode)
Follow steps **2** under "Setting of blinking RPM (**Sport+** mode)".

Available Setting Range
4,000 -to- 14,000 r/min (rpm)