


Switches





Lap button
Operates the lap timer.

▶P.31

Mode button
Changes the riding mode. **▶P.39**

Engine stop switch/

Start button




Should normally remain in the  (Run) position.
▶ In an emergency, switch to the  (Stop) position to stop the engine.

Horn button

Turn signal switch

▶ Pressing the switch turns the turn signal off.

Headlight dimmer switch/Passing light control switch

-  : High beam
-  : Low beam
-  : Flashes the high beam headlight