

# Maintenance

Please read “Importance of Maintenance” and “Maintenance Fundamentals” carefully before attempting any maintenance. Refer to “Specifications” for service data.

An optional larger tool kit may be available. Check with your Honda dealer’s parts department.

<b>Importance of Maintenance</b> .....	P. 31	<b>Air Cleaner</b> .....	P. 64
<b>Maintenance Schedule</b> .....	P. 33	<b>Coolant</b> .....	P. 65
<b>Maintenance Fundamentals</b> .....	P. 36	<b>Brakes</b> .....	P. 67
<b>Removing &amp; Installing Body Components</b> ...	P. 50	<b>Side Stand</b> .....	P. 70
Battery .....	P. 50	<b>Drive Chain</b> .....	P. 71
Clip .....	P. 51	<b>Clutch</b> .....	P. 75
Middle Fairing .....	P. 51	<b>Throttle</b> .....	P. 78
Front Seat .....	P. 53	<b>Crankcase Breather</b> .....	P. 79
Harness Band Clip .....	P. 54	<b>Other Adjustments</b> .....	P. 80
Rear Seat .....	P. 55	Headlight Aim .....	P. 80
Right Under Fairing .....	P. 56	Rear Suspension .....	P. 81
<b>Spark Plug</b> .....	P. 57		
<b>Engine Oil</b> .....	P. 60		