

## Engine

Number .....	113
Oil.....	43, 62
Oil Filter .....	64
Overheats.....	86
Starting .....	27
Stop Switch.....	24, 27, 105
Stopping .....	105
Will Not Start.....	85

## Environment .....

112

## Equipment

Owner's Manual .....	30, 105
Tool Kit.....	30

## F

### Flooded Engine .....

27

### Front Seat .....

54

### Front/Rear Turn Signal Light .....

98

## Fuel

Gauge .....	19
Recommended .....	29
Remaining.....	19
Tank Capacity .....	29

## Fuses.....

42, 100

## G

### Gasohol .....

120

### Gasoline .....

29

## H

### Harness Band Clip .....

55

### Headlight .....

97

### Headlight Aim .....

82

### Headlight Dimmer Switch .....

24

### Helmet Holder.....

30

### High Beam Indicator.....

23

### Honda Contacts .....

123

### Horn Button .....

24

## I

### Ignition Cut-off System

Banking Sensor.....	105
---------------------	-----

Side Stand.....	72
-----------------	----

### Ignition Key.....

104

### Ignition Switch.....

25, 27, 105

### Indicators.....

22

### Information Record.....

129

### Instruments .....

18