


The average fuel mileage and fuel consumption will be based on tripmeter A.

- Current fuel mileage:
Current instant fuel mileage. If your speed is less than 5 mph (7 km/h), "●●●●." is displayed.
When "●●●●." is displayed at speeds above 5 mph (7 km/h), go to your dealer for service.
- Average fuel mileage:
Average fuel mileage since tripmeter A was reset. When "●●●●." is displayed, go to your dealer for service.
- Fuel consumption:
Total fuel consumption since tripmeter A was reset. When "●●●●." is displayed, go to your dealer for service.
- Reserve fuel consumption:
If the engine stop switch is in the  (Stop) position, "●●●●." is displayed. When "●●●●." is displayed in other cases, go to your dealer for service.

► **To reset the average fuel mileage and fuel consumption:**  **P.22**