

# Maintenance

Please read "Importance of Maintenance" and "Maintenance Fundamentals" carefully before attempting any maintenance. Refer to "Specifications" for service data.

An optional larger tool kit may be available.  
Check with your Honda dealer's parts department.

<b>Importance of Maintenance</b> .....	P. 60	<b>Throttle</b> .....	P. 100
<b>Maintenance Schedule</b> .....	P. 62	<b>Other Adjustments</b> .....	P. 101
<b>Maintenance Record</b> .....	P. 65	Adjusting the Headlight Aim .....	P. 101
<b>Maintenance Fundamentals</b> .....	P. 66	Adjusting the Brake Lever .....	P. 102
<b>Removing &amp; Installing Body Components</b> ..	P. 80	Adjusting the Rear Suspension .....	P. 103
Battery .....	P. 80		
Front Seat .....	P. 81		
Rear Seat .....	P. 82		
<b>Engine Oil</b> .....	P. 83		
<b>Coolant</b> .....	P. 87		
<b>Brakes</b> .....	P. 89		
<b>Side Stand</b> .....	P. 92		
<b>Drive Chain</b> .....	P. 93		
<b>Clutch</b> .....	P. 97		