

Adjusting the Headlight Aim

You can adjust vertical aim of the headlight for proper alignment. Turn the screw in or out as necessary using a Phillips screwdriver provided in the tool kit. ➤ P. 37
Obey local laws and regulations.

