

Changing Air Cleaner Element

Use a new Honda Genuine air cleaner element or an equivalent specified for your vehicle.

NOTICE

Using the wrong air cleaner element may cause premature engine wear or performance problems.

1. Remove the left side cover. ➤ P. 72
2. Disconnect the wire connector of the starter magnetic switch. ➤ P. 115
3. Remove the harness band clip from the air cleaner housing cover. ➤ P. 70
4. Remove the air cleaner housing cover by removing the screws.

