



Rear ABS (Anti-lock Brake System) OFF indicator

- Comes on briefly when the ignition switch is turned on.
- Comes on when the ABS function on the rear wheel is turned off.



ABS (Anti-lock Brake System) indicator

Comes on when the ignition switch is turned on.

Goes off when your speed reaches approximately 6 mph (10 km/h).

If it comes on while riding: (P139)