

6. Remove the rear wheel and side collars.
 - u Avoid getting grease, oil, or dirt on the disc to pad surfaces.
 - u Do not push the brake pedal while the wheel is removed.
 - u **CRF1000D**
Do not set the parking brake while the wheel is removed.

Installation

1. To install the rear wheel, reverse the removal procedure.
 - u Take care to prevent the brake caliper from scratching the wheel during installation.

NOTICE

When installing the brake caliper into position, carefully fit the brake disc between the pads to avoid scratching them.