

Instruments *(Continued)*

Press the **MODE** button to move the cursor to a desired display.

Handle grip heater status icon

CRF1000A II/D II

The handle grip heater status icon will appear while the handle grip heater is on. ➔ P.58

EB level ➔ P.64

P level ➔ P.64

Torque Control level ➔ P.61 ➔ P.64

