


## Battery Box Cover



### Removal

1. Remove the bolt using the hex wrench provided on the underside of the front seat. 2 P. 83
2. Remove the battery box cover by releasing its tab from the guide.

### Installation

Install the parts in the reverse order of removal.