



- 10.** Remove the rear wheel and side collars.
- u Avoid getting grease, oil, or dirt on the disc or pad surfaces.
 - u Do not push the brake pedal while the wheel is removed.
 - u **CRF1000D/D II**
Do not set the parking brake while the wheel is removed.

Installation

- 1.** To install the rear wheel, reverse the removal procedure.
 - u Take care to prevent the brake caliper from scratching the wheel during installation.

NOTICE

When installing a wheel or caliper into original position, carefully fit the brake disc between the pads to avoid scratching them.