


## Instruments *(Continued)*

### Side Stand Indicator


The side stand indicator comes on when the side stand is put down. It goes off when the side stand is raised.



**Side stand indicator**

### Air temperature gauge

Displays the ambient temperature.



**Air temperature gauge**