Instruments (Continued)

Display

Following items can be changed sequentially.

- Display Mode (this page)
- Brightness P.80
- Background P.81
- Favorite Information P.83
- Favorite Switch P.85

Display Mode

You can select the riding information image.

