


- 3 Touch the center on each of the four crosses.
- u The screen flashes green when calibration is complete.
If calibration fails, the screen flashes red. Try step 3 again.




- 4 Return to the riding information, previous screen or Home screen. **P.38**
- You can also perform the above settings by using the touch screen.

Service Mode

CRF1100A4/D4

The cornering light can be turned on when the vehicle is stopped for inspection.



- 1 Start the engine. **P.200**
- 2 Stop the vehicle.
- 3 Select [Service Mode], and then press the **ENT** switch.