


Switches

Left handlebar switch  P.114

Right handlebar switch  P.113



 **Ignition switch**

Switches the electrical system on/off, locks the steering.

- u Key can be removed when in the OFF or LOCK position.

Steering Lock:  P.117

ON
Turns electrical system on for starting/riding.

OFF
Turns engine off.

LOCK
Locks steering.

