
7 Press the **b** back switch. You can also perform the above settings by using the touch screen.



When the gold image is selected:



Available settings: [ACTIVE]/[CANCEL]

Default: [ACTIVE]