











## Wheelie Control *(Continued)*

### Wheelie Control Level setting

- When using the  favorite switch:
  - ① Stop the vehicle.
  - ② Select the [Wheelie Control] of the  favorite switch.  P.85
  - ③ Press the  favorite switch.
    - u 3: the maximum wheelie control level [W]
    - u 1: the minimum wheelie control level [W]



- When using the multi-information display:
  - ① Stop the vehicle.
  - ② Select the gold image display.  P.78
  - ③ Select page 4.  P.43
  - ④ Press the **ENT** switch.
  - ⑤ Select [W].
  - ⑥ Push the  or  of the   sel left/right switch to select your preferred level.

