


## Battery Box Cover



### Removal

1. Remove the bolts using the hex wrench provided on the underside of the rear seat. 2 P. 222
2. Remove the battery box cover.

### Installation

Install the parts in the reverse order of removal.