

Subtraction Trip [-TRIP]

Distance travelled is subtracted from a preset figure, since the subtraction trip was set up. Display range: 999.0 to -1,000.0 mile or 1,607.3 to -1,609.0 km. The display locks at “-1000.0” mile (“-1609.0” km) when the read-out exceeds -1000.0 mile (-1609.0 km).

To set the subtraction trip:  **P.75**

Default: 000

1	2	3	4
INST. CONS.	30.0 mpg		
AVG. CONS.	45.0 mpg		
RANGE	20 mile		
-TRIP	50 mile		