


Battery Box Cover



■ Removal

1. Remove the bolts using the hex wrench provided on the underside of the rear seat. ► P. 222
2. Remove the battery box cover.

■ Installation

Install the parts in the reverse order of removal.