Flooded Engine

If the engine fails to start after repeated attempts, it may be flooded with excess fuel. To clear a flooded engine:

Using The Start Button

- 1. Push the choke knob in all the way to OFF.
- 2. Open the throttle fully.
- 3. Press the start button for 5 seconds.
- 4. Follow the *High Air Temperature* starting procedure (page 34).

Using The Kickstarter

- 1. Turn the engine stop switch to OFF (\bigotimes).
- 2. Push the choke knob in all the way to OFF.
- 3. Open the throttle fully.
- 4. Crank the engine several times with the kickstarter.
- 5. Turn the engine stop switch to RUN (\bigcirc).
- 6. Follow the *High Air Temperature* starting procedure (page 34).

How to Stop the Engine

To stop the engine, shift into neutral, turn the engine stop switch to OFF (\bigotimes).