

# Index

---

## H

- Honda service manual ..... 158
- Honda, contacting ..... 162

## I

- idle speed, engine ..... 81
- ignition switch ..... 19
- inspection,
  - post-ride ..... 40
  - pre-ride ..... 27

## K

- key, lost ..... 141
- kickstarter ..... 21

## L

- left fuel tank shroud removal ..... 57
- left side cover removal ..... 56
- lever,
  - front brake ..... 20
  - shift ..... 21
- limit, weight ..... 9
- loading ..... 8

## M

- maintenance,
  - component locations ..... 52
  - record ..... 51
  - safety ..... 45
  - schedule ..... 47
- manual, service ..... 158
- modifications ..... 11