

Index

H

- Honda service manual 157
- Honda, contacting..... 161

I

- ignition switch17
- inspection,
 - post-ride 38
 - pre-ride..... 25

K

- key, lost..... 138
- kickstarter 19

L

- left fuel tank shroud removal 55
- left side cover removal..... 54
- lever,
 - front brake 18
 - shift 19
- limit, weight 9
- loading..... 8

M

- maintenance,
 - component locations 50
 - record 49
 - safety..... 43
 - schedule 45
- manual, service..... 157
- modifications..... 11