

Maintenance Schedule

Items	Frequency	Whichever Comes First ⇒	Initial Maint.	Regular Maint. Interval				Refer to page:
			mi	600	1,200	1,800	2,400	
			km	1,000	2,000	3,000	4,000	
			Note	1	6	12	18	
*	Fuel Line				I		I	–
*	Throttle Operation				I		I	72
	Air Cleaner	Note 1		C	C	C	C	67
	Crankcase Breather			I	I	I	I	71
	Spark Plug			I	I	I	I	78
*	Valve Clearance		I	I	I	I	I	–
	Engine Oil		R	R	R	R	R	61
**	Engine Oil Strainer Screen				C		C	–
**	Engine Oil Centrifugal Filter				C		C	–
**	Engine Idle Speed		I	I	I	I	I	77

* Should be serviced by your dealer, unless the owner has the proper tools and service data and is mechanically qualified. Refer to the official Honda Service Manual (page 160).

** In the interest of safety, we recommend these items be serviced only by your dealer.