

## Is Your Motorcycle Ready to Ride?

---

|                    |   |
|--------------------|---|
| <i>Leaks</i>       | Look under the motorcycle for signs of leaking fluids (fuel, engine oil, brake fluid).  |
| <i>Engine Oil</i>  | Check the level and add oil if needed (page 64).  |
| <i>Fuel</i>        | Check the level and add fuel (page 59) if needed. Also make sure the fuel fill cap is securely fastened.                              |
| <i>Drive Chain</i> | Check the condition and slack. Adjust and lubricate if needed. Also check the chain slider for wear and replace if needed (page 103). |
| <i>Cables</i>      | Check the cable housings for wear. Check the fittings for looseness. Replace or tighten as needed.                                    |

|                             |  |
|-----------------------------|--|
| <i>Nuts &amp; Bolts</i>     | Use a wrench to make sure all accessible nuts, bolts, and fasteners are tight. |
| <i>Spark Plug &amp; Cap</i> | Check for looseness (page 77).   |