Is Your Motorcycle Ready to Ride?

Engine Oil Check the level and add oil if

needed (page 65).

Fuel Check the level and add fuel

(page 60) if needed. Also make sure the fuel fill cap is securely

fastened.

Drive Chain Check the condition and slack.

Adjust and lubricate if needed. Also check the chain guide slider and slipper for wear and replace if needed (page 105).

Cables Check the cable housings for

wear. Check the fittings for looseness. Replace or tighten as

needed.

Nuts & Use a wrench to make sure all

Bolts accessible nuts, bolts, and

fasteners are tight.

Spark Plug Check for looseness

& *Cap* (page 79).