

Index

A

accessories	3
adjustments,	
altitude and temperature	117
carburetor	110
chassis.....	123
control freeplay	46, 49, 51
engine idle speed	48
for competition	93
gearing.....	124
personal fit.....	126
suspension, front.....	94
suspension, rear	102
suspension, track conditions.....	106
tire selection	125
after competition maintenance	26
air cleaner	43
air pressure,	
front suspension.....	94
tires	80
appearance care	90
authorized manuals.....	148

B

basic operation.....	11
before riding	7
between motos & practice maintenance	26
brakes,	
fluid level.....	76
lever, front adjustment.....	75
pad wear	78
pedal height	75
break-in guidelines	16

C

capacity, fuel	34
carburetor,	
adjustment	110
circuit functions	112
components	110
disassembly/assembly	114
idle speed	48
minor adjustments.....	120
optional muffler settings	118
care, appearance	90
chain drive.....	82
chassis adjustments	123
choke knob	13
cleaner, air.....	43
cleaning, appearance care	90
clutch system, adjustment	49
competition logbook	141
consumer information	147
contacting Honda	149
controls, operating.....	5
coolant.....	41
customer service.....	149
cylinder system	62

D

damping adjustments,	
front.....	100
rear	103
dealer, your Honda.....	150
diagram, wiring	146
drive chain.....	82

E

engine,	
flooded.....	13
idle speed.....	48
number.....	134
oil.....	36
pinging.....	34
starting	13
stop button	14
stopping	14
won't start.....	13
environment, protecting.....	130

F

filter,	
air.....	43
oil.....	37
flooded engine, starting	13
fork,	
front suspension adjustment	94
front suspension inspection	70
oil recommendation	72
front brake lever adjustment	75
front suspension maintenance.....	70
fuel,	
line	34
filter	35
recommendation	34
refueling.....	34
system	34
oxygenated.....	140
tank capacity	34
valve	13