

Index

A

- accessories 3
- adjustments,
 - chassis..... 158
 - control freerplay 73, 76
 - for competition 141
 - gearing..... 159
 - idle speed..... 75
 - personal fit..... 161
 - suspension, front..... 145
 - suspension, rear 148
 - suspension, track conditions..... 153
 - tire selection, track condition 160
- after competition maintenance 31
- air cleaner 70
- air pressure,
 - front suspension..... 145
 - tires 124
- apparel, protective 2
- appearance care 139
- authorized manuals 186

B

- basic operation..... 15
- battery 137
- before riding 11
- between motos/races & practice maintenance... 30
- brakes,
 - fluid level..... 120
 - lever, front adjustment..... 119
 - pad wear 122
 - pedal height 119
- break-in guidelines 20

C

- capacity, fuel 44, 54
- care, appearance 139
- chain, drive..... 127
- chassis adjustments 158
- cleaner, air 70
- cleaning, appearance care 139
- clutch system, adjustment 76
- competition logbook 180
- consumer information 185
- contacting Honda 187
- controls..... 5
- coolant..... 68
- customer service..... 185
- cylinder system 95

D

- damping adjustments,
 - front..... 145
 - rear 149
- dealer, your Honda 188
- diagram, wiring..... 184
- drive chain..... 127

E

- engine mode indicator 10
- engine,
 - does not start..... 167
 - idle speed..... 75
 - lacks power..... 167
 - mode select button..... 142
 - number..... 174
 - oil..... 64
 - pinging..... 44, 54
 - starting 17
 - stop button 18
 - stopping 18
- environment, protecting..... 166

F

- filter,
 - air..... 70
 - fuel pump..... 48, 58
 - oil..... 65
- fork,
 - front suspension adjustments..... 145
 - front suspension inspection 102
 - oil recommendation..... 105
- front brake lever adjustment..... 119
- front suspension maintenance..... 145
- fuel..... 44, 54
- fuel,
 - line inspection..... 44, 54
 - line replacement 45, 55
 - oxygenated..... 179
 - pump filter 48, 58
 - refueling..... 44, 54
 - system..... 44, 54
 - tank capacity..... 44, 54