

G

gap, spark plug 81
 gasohol..... 179
 gasoline..... 44, 54
 gearing 159
 guidelines,
 suspension adjustment..... 154

H

handlebar inspection..... 135
 Honda,
 contacting 187
 service manual..... 186
 your dealer 188
 HRC-launch control system 143

I

identification, vehicle 174
 idle knob, fast 17, 75
 idle speed, engine 75
 indicator,
 circuit inspection 8
 DTC index 9
 engine mode 10, 142
 launch control system..... 10, 143
 MIL blink 7
 inspection, pre-ride..... 13
 instruments 5

L

labels, safety 4
 launch control system indicator..... 10
 logbook, competition..... 180

M

maintenance,
 after competition 31
 before & after competition..... 30
 between motos/races & practice
 maintenance 30
 component locations 32
 general competition..... 26
 importance 22
 safety 23
 schedule 24
 manual, service 186
 modifications..... 3

O

oil,
 engine..... 64
 fork 105
 operating instructions..... 15
 operation component locations 6
 optional,
 parts list..... 182
 sprockets 159
 oxygenated fuels 179

P

pads, brake 122
 parts, optional..... 182
 personal fit adjustments 161
 pinging, engine..... 44, 54
 piston, piston rings, piston pin 93
 plug, spark..... 81
 pre-load, rear suspension 148
 pre-ride inspection 13
 protective apparel..... 2

R

rear suspension adjustment..... 148
 riding,
 apparel 2
 basic operation..... 15
 before 11
 important safety information 2
 safety precautions 2

S

safety,
 a few words about..... Safety Messages
 important information..... 2
 important precautions 2
 labels..... 4
 maintenance..... 23
 riding precautions 16
 schedule, maintenance 24
 seat 33
 serial numbers..... 174
 service,
 customer 185
 manuals..... 186
 side stand (CRF250RX) 16, 126
 spare parts 183
 spark knock..... 44, 54
 spark plug,
 maintenance..... 81
 reading 157
 specifications 175
 spring pre-load, rear suspension 148
 starting,
 engine 17
 troubleshooting..... 167
 steering stem inspection 135
 stopping engine..... 18
 storage..... 165
 subframe 40

(cont'd)