

Index

A

accessories	3
adjustments,	
chassis.....	158
control freeplay	73, 76
for competition	141
gearing.....	159
idle speed.....	75
personal fit.....	161
suspension, front.....	145
suspension, rear	148
suspension, track conditions.....	153
tire selection, track condition	160
after competition maintenance	31
air cleaner	70
air pressure,	
front suspension.....	145
tires	124
apparel, protective	2
appearance care	139
authorized manuals.....	186

B

basic operation.....	15
battery	137
before riding	11
between motos/races & practice maintenance...	30
brakes,	
fluid level.....	120
lever, front adjustment.....	119
pad wear	122
pedal height	119
break-in guidelines	20

C

capacity, fuel	44, 54
care, appearance	139
chain, drive.....	127
chassis adjustments	158
cleaner, air.....	70
cleaning, appearance care	139
clutch system, adjustment	76
competition logbook	180
consumer information	185
contacting Honda	187
controls.....	5
coolant.....	68
customer service.....	185
cylinder system	95

D

damping adjustments,	
front.....	145
rear	149
dealer, your Honda.....	188
diagram, wiring	184
drive chain.....	127

E

engine mode indicator	10
engine,	
does not start.....	167
idle speed.....	75
lacks power.....	167
mode select button.....	142
number.....	174
oil.....	64
pinging.....	44, 54
starting	17
stop button	18
stopping	18
environment, protecting	166

F

filter,	
air.....	70
fuel pump.....	48, 58
oil	65
fork,	
front suspension adjustments.....	145
front suspension inspection	102
oil recommendation	105
front brake lever adjustment	119
front suspension maintenance.....	145
fuel	44, 54
fuel,	
line inspection.....	44, 54
line replacement	45, 55
oxygenated.....	179
pump filter	48, 58
refueling.....	44, 54
system.....	44, 54
tank capacity	44, 54