

## MAINTENANCE SCHEDULE – OFF-ROAD USE

All items should be checked before each off-road event. See your dealer unless you are mechanically qualified and have the proper tools.

**Damage from Off-Road use is not covered by the Distributor’s Limited Warranty on your Honda.**

Perform the *Pre-ride Inspection* (page 19) at each scheduled maintenance period.

I: Inspect and Clean, Adjust, Lubricate or Replace if necessary. C: Clean. R: Replace. A: Adjust. L: Lubricate.

ITEMS	FREQUENCY	NOTE	Each race or about 3.5 hours	Every 4 races or about 15.0 hours	Every 8 races or about 30.0 hours	Refer to Page:
FUEL LINE		(NOTE 6)	I		R	61
FUEL PUMP FILTER		(NOTE 6)			R	63 – 67
THROTTLE OPERATION			I			79
AIR FILTER		(NOTE 1)	C			75, 76
CRANKCASE BREATHER			I			77
SPARK PLUG			I			86
VALVE CLEARANCE/DECOMPRESSOR SYSTEM		(NOTE 4)			I	87 – 95
ENGINE OIL		(NOTE 3) (NOTE 5)	I		R	70, 71
ENGINE OIL FILTER		(NOTE 3)			R	70, 71
ENGINE IDLE SPEED			I			80
PISTON AND PISTON RINGS					R	98 – 100
PISTON PIN					R	98 – 100
RADIATOR COOLANT		(NOTE 2)	I			72, 74
COOLING SYSTEM			I			73
DRIVE CHAIN			I, L	R		130 – 132
DRIVE CHAIN SLIDER			I			130
DRIVE CHAIN ROLLER			I			131
DRIVE SPROCKET			I			132
DRIVEN SPROCKET			I			132
BRAKE FLUID		(NOTE 2)	I			123, 124
BRAKE PADS WEAR			I			125
BRAKE SYSTEM			I			122
CLUTCH SYSTEM		(NOTE 5)	I			81 – 85
CONTROL CABLES			I, L			136
EXHAUST PIPE/MUFFLER			I			133 – 135
SUSPENSION			I			105, 121
SWINGARM/SHOCK LINKAGE				L		42, 121
FORK OIL		(NOTE 3)			R	108, 109, 115 – 121
NUTS, BOLTS, FASTENERS			I			137, 181 – 183
WHEELS/TIRES			I			126 – 128
STEERING HEAD BEARINGS					I	136
SIDE STAND			I			129

WE RECOMMEND THESE ITEMS BE SERVICED BY REFERRING TO AN OFFICIAL HONDA SERVICE MANUAL.

This maintenance schedule is based upon average riding condition. Machine subjected to severe use require more frequent servicing.

NOTES:1.Clean after every moto for dusty riding condition.

2. Replace every 2 years. Replacement requires mechanical skill.

3. Replace after the first break-in ride.

4. Inspect after the first break-in ride.

5. Replace the engine oil, if the clutch discs and plates are replaced.

6. Replace every year.