

# Index

## A

- accessories ..... 4
- adjustments,
  - chassis ..... 153
  - control freeplay ..... 72, 75, 116
  - for competition ..... 139
  - personal fit ..... 155
  - suspension, front ..... 140
  - suspension, rear ..... 143
  - suspension, track conditions ..... 148
  - tire selection, track condition ..... 154
- after competition maintenance ..... 41
- air cleaner ..... 69
- air pressure,
  - front suspension ..... 140
  - tires ..... 121
- apparel, protective ..... 2
- appearance care ..... 136
- authorized manuals ..... 182

## B

- backlight brightness adjustment ..... 13
- basic operation ..... 19
- battery ..... 133
- before riding ..... 15
- between motos & practice maintenance ..... 40
- brakes,
  - fluid level ..... 117
  - lever, front adjustment ..... 116
  - pad wear ..... 119
  - pedal height ..... 116
- break-in guidelines ..... 23, 27

## C

- capacity, fuel ..... 54
- care, appearance ..... 136
- chain drive ..... 124
- changing the fuel mileage unit ..... 14
- changing the speed and mileage unit ..... 14
- chassis adjustments ..... 153
- cleaner, air ..... 69
- cleaning, appearance care ..... 136
- competition logbook ..... 176
- consumer information ..... 181
- controls ..... 7
- coolant ..... 66
- customer service ..... 186
- cylinder system ..... 92

## D

- damping adjustments,
  - front ..... 141
  - rear ..... 144
- dealer, your Honda ..... 186
- diagram, wiring ..... 180
- digital clock setting ..... 13
- drive chain ..... 124

## E

- engine,
  - does not start ..... 161
  - flooded ..... 22
  - idle speed ..... 74
  - lacks power ..... 161
  - mode select button ..... 139
  - number ..... 168
  - oil ..... 63
  - pinging ..... 54
  - starting ..... 21
  - stop button ..... 22
  - stopping ..... 22
- environment, protecting ..... 160

## F

- filter,
  - air ..... 69
  - fuel pump ..... 57
  - oil ..... 64
- flooded engine, starting ..... 22
- fork,
  - front suspension adjustment ..... 140
  - front suspension inspection ..... 99
  - oil recommendation ..... 102
- front brake lever adjustment ..... 116
- front suspension maintenance ..... 140
- fuel ..... 54
- fuel mileage meter ..... 12
- fuel,
  - line inspection ..... 55
  - line replacement ..... 55
  - oxygenated ..... 175
  - pump filter ..... 57
  - refueling ..... 54
  - tank capacity ..... 54