



DRIVE CHAIN

Keep chain adjusted and lubricated.
30mm (1 1/4 in.) Freeplay
See owner's manual
for instructions.

