


Maintenance Component Locations

throttle stop screw
(engine idle speed)

air cleaner



choke lever

drive chain