



Cold Engine:

- 1 The fuel valve is  (ON).
- 2 Turn the ignition switch to the  (ON) position.
- 3 Shift the transmission to Neutral (**N** indicator comes on).
- 4 Pull the choke lever back all the way to fully ON (A).
- 5 With the throttle slightly open, press the start button.
- 6 Warm up the engine by opening and closing the throttle slightly.
- 7 Continue warming up the engine until it runs smoothly and responds to the throttle, when the choke lever is at fully OFF (B).