


## Muting

To mute the audio volume — push the MUTE button.

The display will indicate “MUTE”.

To restore the original volume — push the MUTE button again to restore the original volume.

### LEFT HANDLEBAR



MUTE button

MUTE indicator

