

# Multi Information Display

7. Use the INFO and TRIP buttons to cycle through the alphabet, number and symbol selection.

## Capital Letters


A B C D E F G H I J K L M N O P Q R S T U V W X Y Z

## Numbers

0 1 2 3 4 5 6 7 8 9

## Symbols

! " # \$ % & ' ( ) \* + , - . / > = < ?



8. When you have completed your message, push the SETUP button to select the "SET" function which will lock in your special message to be used for the opening and ending ceremony.

When approximately 5 seconds pass without operating a button, the display automatically returns to the previous display.