


Multi Information Display

Changing the Information Display

The display changes as follows each time the INFO button is pushed.

When approximately 5 seconds pass without operating a button, the display automatically returns to the previous display.

(Models not equipped with Navigation System)



(Models equipped with Navigation System)

