


Muting

To mute the audio and navi volume — push the MUTE button.

The display will indicate “MUTE”.

To restore the original volume — push the MUTE button again to restore the original volume.


LEFT HANDLEBAR



MUTE button

(Models not equipped with Navigation System)

MUTE indicator



(Models equipped with Navigation System)

MUTE indicator

