


# iPod®/USB Flash Drive

## Playing an iPod®

Connect the iPod® using your dock connector to the USB cable (see [page 134](#) ), then push the AUX button twice and iPod® indicator will be displayed. If you see an error message in the display, see [page 143](#) .

(Models not equipped with Navigation System)



(Models equipped with Navigation System)

