












## To Connect the Paired Device Manually

Icon status:

-  (light blue) : phone function connected
-  : phone function unconnected
-  (light blue) : music function connected
-  : music function unconnected



- 1 Select [Bluetooth setting], and then press  or **ENT** switch.
- 2 Select [Phone pairing], [Rider HS pairing] or [Passenger HS pairing], and then press  or **ENT** switch to enter the setting menu.
- 3 Select the device you want to connect, and then press  or **ENT** switch.
- 4 When the connection is established, a message to inform you that pairing was successful appears on the screen. Press  or **ENT** switch.

- 5  (*Bluetooth*<sup>®</sup> icon) and  (device icon) appear on the upper part of the screen, and icons of available functions appear next to the name of the device and turn on in light blue.

▶ The battery status of the device icon is displayed only when Phone connection is established.

## To Reconnect a Paired Device Automatically

When the ignition switch is turned ON or ACC, the system reconnects with registered device automatically.

- ▶ If the system finds multiple paired devices, the system will reconnect with the device that was connected last.
- ▶ After reconnecting, the song that was last played will be played automatically.