

## When the Honda SMART Key System Does Not Operate Properly

When the Honda SMART Key system does not work properly, perform the following.

- Check that the Honda SMART Key system is activated.  
Lightly press the ON/OFF button on the Honda SMART Key.  
If the LED of the Honda SMART Key does not blink 3 times, switch the Honda SMART Key system to activation. ➤ P. 56  
If the LED of the Honda SMART Key does not respond, replace the battery of the Honda SMART Key. ➤ P. 174
- Check that there is no communication failure in the Honda SMART Key system. The Honda SMART Key system uses low-intensity radio waves. The Honda SMART Key system may not work properly in the following environments:
  - ▶ When there are facilities nearby that generate strong radio waves or noise such as TV towers, power stations, radio stations, or airports.
  - ▶ When you carry the Honda SMART Key with a laptop or wireless communication device such as a radio or mobile phone.

▶ When the Honda SMART Key comes into contact with or is covered by metal objects.

- Check that a registered Honda SMART Key is used.  
Use a registered Honda SMART Key. The Honda SMART Key system cannot be activated without a registered Honda SMART Key.
  - Make sure that you do not use a broken Honda SMART Key.  
If you use a broken Honda SMART Key, the Honda SMART Key system cannot be activated. Bring the emergency key and ID tag to your dealer.
  - Check the battery condition and battery lead in your motorcycle.  
Check the battery and battery terminals. If the battery is weak, contact your dealer.
- If the Honda SMART Key system cannot be activated due to other causes, contact your dealer.