







Labels

The following pages show the meanings and locations of the labels on your Cota.
Others provide important safety information. Read this information carefully and don't remove the labels.
If a label comes off or becomes hard to read, contact your dealer for a replacement.
There is a specific symbol on each label. The meanings of each symbol and label are as follows.

1		Tire information (2ED) - Cold tire pressure (driver only) Front: 100kpa Rear: 100kpa
2		Keep chain adjusted and lubricated - 25-35 Mm (1.0 -1.4 In) Read owners manual
3		Caution label - For your protection always wear your helmet while riding. - Read owner's manual carefully - Petrol fuel containing up to 10% ethanol - Use unleaded gasoline, octane number 95 (RON) or higher.
4		Radiator cap label - Danger - Never open when hot. - Hot coolant will scald you. - Relief pressure valve begins to open at 1.1 Kg/cm ² .
5		Safety label (4ED) (*) Depending on the final destination of the motorcycle
6		EC label