















Service and maintenance

ITEM	FREQUENCY	Pre-ride check									Remarks		
			500 Km.	1.500 Km.	3.000 Km.	4.500 Km.	6.000 Km.	Every 6 months	Yearly check	Every 2 years			
Fuel filter											I		
Clean under the front suspension fender											I		
Air cleaner			C	R	R	R	R	R					Check the air cleaner after riding in dusty areas.
Spark Plug					I			R					
Valve clearance			I		I			I					
Crankcase breather				C	C	C	C	C			C		
Engine oil filter			R	R	R	R	R	R			R		
Engine oil filter screen			C	C	C	C	C	C					
Engine idle speed			I	I	I	I	I	I			I		
Radiator coolant			I	I	I	I	I	I			I	R	
Cooling system			I	I	I	I	I	I			I		
Drive chain slider / tensioner			I	I	I	I	I	I					Check the item after riding in adverse conditions and dusty areas.
Drive / driven sprocket			I	I	I	I	I	I					
Drive chain slider			I	I	I	I	I	I					
Brake system			I	I	I	I	I	I			I		
Clutch fluid			I	I	I	I	I	I			I	R	
Rear suspension			I	I	I	I	I	I			I		Check the items more often when riding in adverse conditions and dusty areas.
Damper linkage / rods			I	I	I	I	I	I			I		
Fork oil												R	
Steering pipe bearing			I	I	I	I	I	I			I		
Wheel bearings					R			R					
Nuts, bolts and fasteners			I	I	I	I	I	I			I		