


Instruments *(continued)*

Setting mode

The main screen is used to adjust the following settings:


1. Changing the speed units:

- 1 Start the motorcycle.
- 2 Press the (SET) button.
 - ▶ Press less than 2 seconds to display the ride time (hour) or mileage (km / mi).
 - ▶ Press and hold more than 10 seconds, the speed units will change from km/h to mph and vice versa, depending on their initial setting.



2. Changing from "TOTAL", "Trip A" o "Trip B".

- 1 Start the motorcycle.
The "TOTAL" distance is displayed by default.
- 2 Press the (MODE) button.
 - ▶ Press less than 2 seconds to display "TOTAL", "TRIP A" o "TRIP B".
- 3 Press the (SET) button.
 - ▶ Press less than 2 seconds to display the ride time (hour) or accumulated mileage (km/mi).



To reset "TRIP A" or "TRIP B", select the desired condition (accumulated mileage or ride time). Press and hold the (SET) button for more than 2 seconds.